

"AZIOTROPIC FLASH DRY"

1. SCRUB with StoneClean "104" in a 1:50 DILUTION. (This step can be eliminated if surface is clean).
2. RINSE as BRUSH SCRUB with 50:50 METHANOL//WATER dilution.
BLOT WITH PAPER TOWEL.
3. REPEAT Step 2. [This is to get any oils etc. out of floor].
4. USING CLEAN or NEW SPONGE, BLOT with 100% METHANOL.
5. *DRY with heat lamps//box fans.*
6. MIX, INDUCT/CATALYZE and APPLY SEALER. [If 200-Series, use "HOT" Accelerated to WARM FLOOR. (POT LIFE is max. 1 hour!)
7. WHEN PRINT FREE, repeat step 6.

Subject to RJSC MSDS' and Limited Warranty.